

Leijona 1300 Controller indicator light fault code

- (1) The indicating light is off: the motor is running normally
- (2) Light flashes once, the controller enters the Standby state; in this case the rotation turn the display light is off, the motor is running normally.
- (3) Light flash twice: brake fault.
- (4) Light flashes three times: MOS, the drive circuit fault, LM358 damage.
- (5) Lights flashes four times: the anti-fly-over protection; the Find method: turn to not return to zero, turn the signal line and the 4. 3V short-circuit or into off the ground anti-flying car.
- (6) Lights flashes five times: current fault
- (7) Lights flashes six times: undervoltage protection;
- (8) Lights flashes seven times: locked rotor protection: lookup method: check the motor Hall line contact is normal, whether the motor is in the stall state.
- (9) Light flashes eight times: turn signal open circuit, short circuit or turn to not connected.
- (10) Lights flashes nine times: a self-learning fault, according to the General EA controller repair.

(11) lights flash ten times: the controller into non-Hall State.